


Model No.DUS054 CORDLESS GARDEN SPRAYER



Model No.DUS054 CORDLESS GARDEN SPRAYER

Obj. č.	Obj. č.	Popis	Možn ost zá měny	Množ ství	Nový/ Starý	Poznámka 1	Poznámka 2
001	PR00000128	SHOULDER STRAP		1		popruh	
002	PR00000206	WARNING TEXT LABEL-EN		1			
003	PR00000225	RATING LABEL-0014		1			
004	PR00000183	TAPPINNG SCREW ST4.0X16		6			
005	PR00000182	TAPPINNG SCREW ST2.9X12		2			
006	PR00000191	SPRAY WAND HOLDER		1	*	dr	
006-1	PR00000191	SPRAY WAND HOLDER	O	1		dr	
007	PR00000192	HOUSING SET		1		obal	
007		INC. 52					
008	PR00000183	TAPPINNG SCREW ST4.0X16		4			
009	PR00000193	BATTERY HOUSING		1		obal	
009		INC. 16					
010	PR00000130	DAM-BOARD		1			
011	PR00000194	SPRING		2		pru	
012	PR00000132	TAPPING SCREW ST4.0X12		2			
013	PR00000133	INDICATION LABEL		1		kryt ukazatele	
014	PR00000195	BATTERY TERMINAL		1	*	termin	
014-1	PR00000195	BATTERY TERMINAL	O	1		termin	
015	PR00000196	PCB		1		deska	
016	PR00000193	BATTERY HOUSING		1		obal	
016		INC. 9					
017	PR00000136	SWITCH		1			
018	PR00000137	SPRAY HEAD		2		hlava trysky	
019	PR00000186	O RING 6X2		1		o krou	
020	PR00000138	NOZZLE HOLDER		1			
020		INC. 19					
021	PR00000186	O RING 6X2		1		o krou	
022	PR00000186	O RING 6X2		1		o krou	
023	PR00000139	ROD JOINT		1		ventil	
023		INC. 21,22					
024	PR00000186	O RING 6X2		1		o krou	
025	PR00000140	END CAP		1			
025		INC. 24					
026	PR00000186	O RING 6X2		1		o krou	
027	PR00000141	ADJUSTING KNOB		1			
027		INC. 26					
028	PR00000142	TWO HEAD NOZZLE		1		tryska	
028		INC. 18,20,23,25,27					
029	PR00000143	SEAL PAD 9X17X2		1			
030	PR00000144	HOOK		1		h	
031	PR00000145	SPRAY WAND		1		trubka	
031		INC. 29					
032	PR00000146	O SEAL RING 4.5X1.5		1			
033	PR00000147	FILTER ASSEMBLY		1		dr	
033		INC. 32					
034	PR00000148	HANDLE TRIGGER ASSEMBLY		1		spou	
035	PR00000149	O RING 8X1.8		1			
036	PR00000150	SPRING		1			

037	PR00000204	O RING 6X2		1	*		
037-1	PR00000186	O RING 6X2	O	1		o krou	
038	PR00000205	O RING 3X1.5		2		o krou	
039	PR00000151	VALVE ROD		1		ty	
039		INC. 38					
040	PR00000190	O RING 12X2		1	*	o krou	
040-1	PR00000190	O RING 12X2	O	1		o krou	
041	PR00000152	LOCK COVER		1			
042	PR00000182	TAPPINNG SCREW ST2.9X12		1			
043	PR00000153	HANDLE SET		1	*	dr	
043-1	PR00000502	HANDLE SET	<	1		dr	
044	PR00000182	TAPPINNG SCREW ST2.9X12		5			
045	PR00000154	SPRAY HOSE ASSEMBLY		1	*	dr	
045		INC. 35,36,37,39,40,41			*		
045-1	PR00000499	SPRAY HOSE ASSEMBLY	S	1		dr	
045-1		INC. 35,36,37,39,40,41					
046	PR00000155	GROMMET		1	*	pouzdro	
046-1	PR00000155	GROMMET	O	1		pouzdro	
047	PR00000184	SNAPPER HOSE CLAMP (L)		1	*	svorka	
047-1	PR00000184	SNAPPER HOSE CLAMP (L)	O	1		svorka	
048	PR00000211	WARNING LOGO LABEL		1			
049	PR00000182	TAPPINNG SCREW ST2.9X12		2			
050	PR00000191	SPRAY WAND HOLDER		1	*	dr	
050-1	PR00000191	SPRAY WAND HOLDER	O	1		dr	
051	PR00000197	DECORATION LABEL		1			
052	PR00000192	HOUSING SET		1		obal	
052		INC. 7					
053	PR00000198	BATTERY COVER SEAL PAD		1		t	
054	PR00000159	BATTERY COVER BUTTON		1		tla	
055	PR00000160	SPRING		1		pru	
056	PR00000199	BATTERY COVER		1		kryt	
057	PR00000162	PRESS-BUTTON		1		tla	
058	PR00000007	TAPPING SCREW ST2.9X15		1	*		
058-1	PR00000007	TAPPING SCREW ST2.9X15	O	1			
059	PR00000163	SHAFT		1		h	
060	PR00000183	TAPPINNG SCREW ST4.0X16		2			
061	PR00000164	MOTOR FIXED BLOCK		1		blok motoru	
062	PR00000165	SHOCK ABSORBER RING		1			
063	PR00000183	TAPPINNG SCREW ST4.0X16		2			
064	PR00000166	INLET CONNECTION		1			
065	PR00000188	HOSE CLIP		1			
066	PR00000187	DELIVERY TUBE (55MM)		1			
067	PR00000167	SPRING		1			
068	PR00000188	HOSE CLIP		1			
069	PR00000190	O RING 12X2		1	*	o krou	
069-1	PR00000190	O RING 12X2	O	1		o krou	
070	PR00000200	PUMP UNIT WITH MOTOR		1			
071	PR00000184	SNAPPER HOSE CLAMP (L)		2	*	svorka	
071-1	PR00000247	SNAPPER HOSE CLAMP (S)	X	2	*	svorka =old PR00000184	
071-2	PR00000247	SNAPPER HOSE CLAMP (S)	O	2		svorka =old PR00000184	

072	PR00000187	DELIVERY TUBE (55MM)		1	*		
072-1	PR00000248	DELIVERY TUBE (48MM)	X	1		trubka 48mm	
073	PR00000187	DELIVERY TUBE (55MM)		1	*		
073-1	PR00000249	DELIVERY TUBE (40MM)	X	1		trubka 40mm	
074	PR00000184	SNAPPER HOSE CLAMP (L)		1	*	svorka	
074-1	PR00000247	SNAPPER HOSE CLAMP (S)	X	1	*	svorka =old PR00000184	
074-2	PR00000247	SNAPPER HOSE CLAMP (S)	O	1		svorka =old PR00000184	
075	PR00000188	HOSE CLIP		1			
076	PR00000169	CHECK VALVE ASSEMBLY		1		ventil	
077	PR00000170	WATER INLET		1	*		
077-1	PR00000170	WATER INLET	O	1			
078	PR00000201	PUMP ASSY		1	*		
078		INC. 62,64-68,70-77			*		
078-1	PR00000201	PUMP ASSY	O	1			
078-1		INC. 62,64-68,70-77					
079	PR00000183	TAPPINNG SCREW ST4.0X16		2			
080	PR00000172	BASE BOARD		1		deska	
081	PR00000183	TAPPINNG SCREW ST4.0X16		4			
082	PR00000173	O RING 17X2		1		o krou	
083	PR00000186	O RING 6X2		1		o krou	
084	PR00000174	KNOB LOCK CAP ASSEMBLY		1		z	
084		INC. 83					
085	PR00000175	SEAL PAD FOR TANK		1	*	podlo	
085-1	PR00000175	SEAL PAD FOR TANK	X	1		podlo	
086	PR00000176	SUCTION TUBE 190MM		1	*	trubka	
086-1	PR00000176	SUCTION TUBE 190MM	O	1		trubka	
087	PR00000177	FILTER		1		filtr	
088	PR00000178	TANK (LITRE)		1	*	n	
088-1	PR00000178	TANK (LITRE)	X	1		n	
089	PR00000179	O RING 34X3.5		1			
090	PR00000180	TANK CAP WITH MEASURING CUP (M)		1	*	v	
090		INC. 89			*		
090-1	PR00000180	TANK CAP WITH MEASURING CUP (M)	X	1		v	
090-1		INC. 89					
091	PR00000181	FILTER CARTRIDGE		1		vlo	
093	PR00000247	SNAPPER HOSE CLAMP (S)		1	*	svorka =old PR00000184	
093-1	PR00000247	SNAPPER HOSE CLAMP (S)	O	1		svorka =old PR00000184	
096	687010-0	pružina		1		pru	