


Model No. UC015G 350MM CORDLESS CHAIN SAW



Model No.UC015G 350MM CORDLESS CHAIN SAW

Obj. č.	Obj. č.	Popis	Možn ost zá měny	Množ ství	Nový/ Starý	Poznámka 1	Poznámka 2
001	327932-9	FRONT HANDLE		1		p	
002	911218-7	Pan Head Screw M5x14=new922 217-4		2			
003	911218-7	Pan Head Screw M5x14=new922 217-4		2			
004	122A77-2	TANK CAP ASSEMBLY		1		v	
004		INC. 5					
005	213080-9	O RING 29.5		1			
006	422835-3	OIL TUBE 3-117		1		olejov	
007	266326-2	šroub 4x18=new265995-6		2			
008	142857-4	OIL PUMP COMPLETE		1			
009	961011-9	zajišťovací kroužek		1		zaji	
010	226884-0	WORM GEAR		1		p	
011	422836-1	OIL TUBE 3-108		1		olejov	
012	231975-4	pružina DCS230T/UC3020A=old0 21245060		1		pru	
013	452666-6	NIPPLE		1			
014	911228-4	šroub M5x18		3			
015	413C89-1	MOTOR HOUSING		1		sk	
016	620H71-5	CONTROLLER		1	*	ovlada	
016-1	620P46-2	CONTROLLER	S	1			
017	266490-9	TAPPING SCREW PT 2X6		3			
018	687B69-9	STOPPER		1		zar	
019	620H75-7	CONTROLLER B		1		ovlada	
020	652031-1	PAN HEAD SCREW M3X6		3			
021	629B00-9	STATOR		1		stator	
022	632T19-7	LEAD UNIT		1		vedouc	
023	413C90-6	BAFFLE PLATE		1		p	
024	266326-2	šroub 4x18=new265995-6		2			
025	210016-9	BALL BEARING 698ZZ		1		kuli	
026	519732-3	ROTOR ASS'Y		1	*	rotor ass'y	
026		INC. 25,27			*		
026-1	519732-3	ROTOR ASS'Y	O	1		rotor ass'y	
026-1		INC. 25,27					
027	210059-1	BALL BEARING 6000DDW		1			
028	911118-1	šroub M4x12		2			
029	413C92-2	FRONT HAND GUARD RETAINER		1		dr	
030	213594-8	O RING 7		1		o-krou	
031	141J69-6	FRONT HAND GUARD COMPLETE		1		chr	
C10	8050E6-6	CAUTION LABEL		1			
033	136612-4	HOUSING BASE ASSEMBLY		1		z	
C10	263002-9	vymezovací čep 4		1			
034	313398-9	HAND GUARD GUIDE		1		chr	
035	234210-9	COMPRESSION SPRING 3		1		pru	
036	413D07-5	GUARD A		1		chr	
037	422834-5	GROMMET A		1		tesn	
038	413D08-3	GUARD B		1		chr	
039	347924-2	CHAIN CATCHER		1		kryt	
040	266034-5	šroub = old 933417		1			

041	347925-0	SPIKE BUMPER		1		doraz	
042	266034-5	šroub = old 933417		1			
045	227496-2	ozubené kolo UC3020A=old226213320		1		ozuben	
046	326310-0	ADJUST PIN		1			
047	327958-1	ADJUST SCREW		1		se	
048	413F29-7	COVER		1		kryt	
049	266427-6	TAPPING SCREW 4X12		1	*		
049-1	265C54-4	TAPPING SCREW 4X12	O	1			
050	141E60-4	LINK PLATE COMPLETE		1		deska	
051	232452-9	COMPRESSION SPRING 7		1		pru	
052	347922-6	BRAKE BAND COMPLETE		1		brzdov	
053	213060-5	O RING 10		1		o-krou	
054	162979-4	BRAKE DRUM		1		brzdov	
055	191V91-5	SPROCKET 7 SET		1			
056	961013-5	zajišťovací kroužek		1		zaji	
057	413C95-6	BRAKE COVER		1		kryt brzdy	
058	266034-5	šroub = old 933417		6			
059	413C88-3	BATTERY COVER		1		kryt baterie	
060	8117L7-5	UC015G NAME PLATE		1			
061	136689-9	HOUSING L ASSEMBLY		1	*	obal	
061		INC. 59,62			*		
061-1	137024-4	HOUSING L ASSEMBLY	S	1			
061-1		INC. 59,62					
062	266326-2	šroub 4x18=new265995-6		4			
063	266326-2	šroub 4x18=new265995-6		9			
064	620J22-0	SWITCH CIRCUIT COMPLETE		1		sp	
C10	810D46-0	SWITCH LABEL		1			
065	232733-1	TORSION SPRING 10		1	*	pru	
065-1	232850-7	TORSION SPRING 10	S	1		pru	
066	413C94-8	CATCH LEVER		1	*	z	
066-1	141V01-2	LOCK OFF LEVER COMPLETE	S	1		p	
067	650024-2	SWITCH C3JR-4B-PAND4-1		1		sp	
068	632T50-3	SWITCH UNIT		1		sp	
069	413C93-0	SWITCH LEVER		1		p	
070	632L49-0	SWITCH UNIT		1	*	vyp	
071	8117M0-6	UC015G SERIAL NO. LABEL		1			
072	632T07-4	TERMINAL UNIT		1		koncov	
073	652031-1	PAN HEAD SCREW M3X6		2			
074	266326-2	šroub 4x18=new265995-6		3			
075	266326-2	šroub 4x18=new265995-6		2			
076	183V16-3	TERMINAL BOX SET		1		svorkovnice	
C10	263005-3	vymezovací čep 6		2			
080	911228-4	šroub M5x18		4			
081	136674-2	HOUSING R ASSEMBLY		1	*	pouzdro	
C10	8025F3-0	XGT LOGO LABEL		1	*		
081-1	137216-5	HOUSING R ASS'Y	S	1			
C10	8025F3-0	XGT LOGO LABEL		1			
084	413F27-1	GUARD C		1		chr	
085	413F28-9	GUARD D		1		chr	
086	422833-7	GROMMET		1		t	
087	422832-9	CHIP GUIDE		1		veden	

088	413F26-3	INNER COVER		1		vnit	
089	266427-6	TAPPING SCREW 4X12		2	*		
089-1	265C54-4	TAPPING SCREW 4X12	O	2			
090	266427-6	TAPPING SCREW 4X12		3	*		
090-1	265C54-4	TAPPING SCREW 4X12	O	3			
091	413F24-7	SPROCKET COVER		1		kryt	
092	142235-8	NUT COMPLETE		1		up	
093	413F25-5	NUT COVER		1		kryt	
094	263002-9	vymezovací čep 4		1			
095	142665-3	DRIVE GEAR COMPLETE		1		nap	
096	183W23-2	SPROCKET COVER SET		1		sada kryt	
096		INC. 45-49,84-95					
A01	191T87-4	GUIDE BAR 14 SET		1			
A02	419288-5	kryt pro UC3020/3520A		1	*		
A02-1	419288-5	kryt pro UC3020/3520A	O	1			
A04	191T91-3	SAW CHAIN 14 SET		1			
A05	782023-7	WRENCH 13-16		1			
A07	412393-7	BATTERY COVER		1	*		
A08	***DC40RA	DC40RA FAST CHARGER		1			
A08		COMPO-PARTS					
A09	191L47-8	BATTERY BL4050F SET		1			
E01	8050E9-0	SOUND LABEL		1			
F01	191G24-0	GUIDE BAR 14 SET		1			
F02	191G25-8	GUIDE BAR 16 SET		1			
F03	191G26-6	GUIDE BAR 18 SET		1			
F04	191H11-5	SAW CHAIN 14 SET		1			
F05	191H12-3	SAW CHAIN 16 SET		1			
F06	191H13-1	SAW CHAIN 18 SET		1			
F13	191V90-7	SPROCKET 6 SET		1			
F14	191V91-5	SPROCKET 7 SET		1			
F17	195093-1	CHAIN OIL SET		1			
F18	198457-8	CHAIN EDGER SET		1	*		
F18-1	D-70948	FILE HOLDER SET 4.0MM(5/32")	O	1			

Prosím uveďte objednáací číslo dílu v objednávce

Datum tisku 06. 11. 2024